



Typical installation of
Spark Gap
EX-FS-KU



Typical installation
of
Spark Gap
EX-FS